

Premier Date and Time

Change Time and Date

While on hook press Spcl (special) and dial 021.

Enter HHMM then press * for AM or # PM.

Displays Set Date MMDDYYYY

Displays Set Day of Week (Sun)

Scroll through the day of week by pressing # to go forward or * to go backward.

When the desired day is displayed, press Speaker. You hear a progress tone.